


SERIE 911		
CODO 45° MF/MF ASIENTO CONICO NPT/CONICO NPT		
CODIGO	ROSCA NPT	ROSCA NPT
911-04-04	1/4"	1/4"
911-04-06	1/4"	3/8"
911-06-06	3/8"	3/8"
911-06-08	3/8"	1/2"
911-08-08	1/2"	1/2"
911-12-12	3/4"	3/4"
911-16-16	1"	1"

SERIE 911 i (HEMBRA)		
CODO 45° HF/MF CIERRE CONICO NPT/CONICO NPT		
CODIGO	ROSCA NPT	ROSCA NPT
911i-02i-02	1/8"	1/8"
911i-04i-04	1/4"	1/4"
911i-06i-06	3/8"	3/8"
911i-08i-08	1/2"	1/2"
911i-12i-12	3/4"	3/4"
911i-16i-16	1"	1"

SERIE 921		
CODO 45° MF/MF ASIENTO VIROLA UNF/CONICO NPT		
CODIGO	ROSCA NPT	ROSCA NPT
921-04-04	9/16"	1/4"
921-04-06	9/16"	3/8"
921-06-04	3/4"	1/4"
921-06-06	3/4"	3/8"
921-06-08	3/4"	1/2"
921-08-06	7/8"	3/8"
921-08-08	7/8"	1/2"
921-10-08	1" 1/16	1/2"
921-10-12	1" 1/16	3/4"
921-12-12	1" 3/16	3/4"
921-14-12	1" 5/16	3/4"
921-14-16	1" 5/16	1"



SERIE 928		
CODO 45° MF/MF ASIENTO VIOLA UNF/O´RING UNF		
CODIGO	ROSCA UNF	ROSCA UNF
928-04-04	9/16"	9/16"
928-06-06	3/4"	3/4"
928-08-06	7/8"	3/4"
928-08-08	7/8"	7/8"
928-10-10	1" 1/16	1" 1/16
928-12-10	1" 3/16	1" 1/16
928-12-12	1" 3/16	1" 3/16
928-14-14	1" 5/16	1" 5/16

SERIE 931		
CODO 45° HG/MF ASIENTO VIOLA UNF/CONICO NPT		
CODIGO	ROSCA UNF	ROSCA NPT
931-04-04	9/16"	1/4"
931-06-06	3/4"	3/8"
931-06-08	3/4"	1/2"
931-08-08	7/8"	1/2"
931-10-12	1" 1/16	3/4"
931-12-12	1" 3/16	3/4"

SERIE 931 B		
CODO 45° HG/MF ASIENTO VIOLA BSPP/CONICO NPT		
CODIGO	ROSCA BSPP	ROSCA NPT
931B-04-04	1/4"	1/4"
931B-06-06	3/8"	3/8"
931B-06-08	3/8"	1/2"
931B-08-06	1/2"	3/8"
931B-08-08	1/2"	1/2"
931B-10-12	5/8"	3/4"
931B-12-12	3/4"	3/4"

SERIE 938 B		
CODO 45° HG/MF ASIENTO SAE 30° BSPP/O´RING UNF		
CODIGO	ROSCA BSPP	ROSCA UNF
938B-04-04	1/4"	9/16"
938B-06-06	3/8"	3/4"
938B-06-08	3/8"	7/8"
938B-08-08	1/2"	7/8"

SERIE 941		
CODO 45° MF/MF ASIENTO JIC 37° UNF/CONICO NPT		
CODIGO	ROSCA UNF	ROSCA NPT
941-03-04	1/2"	1/4"
941-04-04	9/16"	1/4"
941-04-06	9/16"	3/8"
941-06-06	3/4"	3/8"
941-06-08	3/4"	1/2"
941-08-06	7/8"	3/8"
941-08-08	7/8"	1/2"
941-10-12	1" 1/16	3/4"
941-12-12	1" 3/16	3/4"
941-14-12	1" 5/16	3/4"
941-14-16	1" 5/16	1"

SERIE 948		
CODO 45° MF/MF ASIENTO JIC 37° UNF/O´RING UNF		
CODIGO	ROSCA UNF	ROSCA UNF
948-04-04	9/16"	9/16"
948-04-06	9/16"	3/4"
948-06-04	3/4"	9/16"
948-06-06	3/4"	3/4"
948-06-08	3/4"	7/8"
948-08-06	7/8"	3/4"
948-08-08	7/8"	7/8"
948-10-10	1" 1/16	1" 1/16
948-10-12	1" 1/16	1" 3/16
948-12-10	1" 3/16	1" 1/16
948-12-12	1" 3/16	1" 3/16
948-14-14	1" 5/16	1" 5/16

SERIE 951		
CODO 45° HG/MF CIERRE JIC 37° UNF/CONICO NPT		
CODIGO	ROSCA UNF	ROSCA NPT
951-04-04	9/16"	1/4"
951-06-06	3/4"	3/8"
951-08-06	7/8"	3/8"
951-08-08	7/8"	1/2"
951-10-12	1" 1/16	3/4"
951-12-12	1" 3/16	3/4"
951-14-12	1" 5/16	3/4"

